

Architectural Door Accessories

ASSA ABLOY

Pemko Door Bottoms

The global leader in
door opening solutions

Applies to the following door bottom:

2343_V


Installation Instructions:

1. To install, door must be removed.
2. Measure, mark and trim door bottom shoe to full width of door.
Trim seal 1/16" longer than trimmed door shoe at each end.
3. Remove vinyl.
4. Fasten door bottom shoe to bottom of door with supplied screws.
5. Replace vinyl. Crimp ends to secure insert.

Testing/Ratings:



Tools Required:



www.pemko.com

MEMPHIS, TN USA VENTURA, CA USA VANCOUVER, BC CA TORONTO, ON CA
P: 800 824-3018 P: 800 283-9988 P: 877 535-7888 P: 877 535-7888
F: 800 243-3656 F: 800 283-4050 F: 877 535-7444 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DBS_WEBINS
Rev 2 - 03.07.17
Page 1 of 1