

Architectural Door Accessories

ASSA ABLOY

Pemko Door Bottoms

The global leader in
door opening solutions

Applies to the following door bottom:

368_N, 315_N, 315SSN, 321SSN, 321_N

Installation Instructions:

1. Measure, mark and trim door bottom sweep to full width of the door.
2. Drill pilot holes in door at marks.
3. Mount to door with supplied fasteners.


Testing/Ratings:

Gasketing material for fire doors intended for application to listed steel frames and/or classified steel covered composite type, and hollow metal type fire doors rated up to 3 hours; wood and plastic covered composite type fire doors rated up to 1-1/2 hours; and wood core type fire doors rated up to 20 minutes.

(Thresholds may or may not contain gasketing material).



Tools Required:



www.pemko.com

MEMPHIS, TN USA VENTURA, CA USA VANCOUVER, BC CA TORONTO, ON CA
P: 800 824-3018 P: 800 283-9988 P: 877 535-7888 P: 877 535-7888
F: 800 243-3656 F: 800 283-4050 F: 877 535-7444 F: 877 535-7444

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

DBS_WEBINS
Rev 2 - 03.07.17
Page 1 of 1