


# S88 INSTALLATION LOCATIONS:



## Hinge Jamb

Application is acceptable anywhere along jamb face (door must be able to operate properly).





## Header

Application is acceptable anywhere along jamb face (door must be able to operate properly).



## Strike Jamb

Application is acceptable anywhere along jamb face (door must be able to operate properly).



S88\_App1.eps  
Rev 1, 02/2008

Copyright © 2008 Pemko Manufacturing Company. All rights reserved. Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.